



INSTALLATION STEPS



STEP 1

Install socket tile at the ventilation pipe.



STEP 2

Fix socket sleeve on socket tile and ventilation pipe.



STEP 3

Apply bonding mastic around the neck of socket tile. And place lantern onto it.

Colors Available : Natural terracotta Black